

RYUNIX



FO-104

REMOVABLE MECHANICAL GAMING KEYBOARD

MANUAL BOOK



FO-104 KEYBOARD MANUAL

[EN]



1. Features

- **Fullsize Keyboard Layout**

Mechanical keyboard with 104 keys

- **Removable Switch (3-Pin)**

Equipped with an outemu switch that can be replaced with other switches

- **LED Light Effects**

Easily change LED light effects with 6 buttons

- **Shortcut Button**

12 shortcut keys for multimedia functions

- **Full-Keys Anti-Ghosting**

All keys are anti-ghosting for good typing

- **USB Wired Connection**

Keyboard connection with 1.8m USB PVC cable

2. Specifications

Number of Keys : 104 Keys + 12 Hotkeys

Anti-Ghosting : Full Anti-Ghosting

Keyboard Type : Mechanical Keyboard

Switch : Removable Outemu Switch

Connection : USB

Cable Length : 1.8m

Cable Type : PVC Cable

Backlight : RGB Backlight
6-Level Brightness Adjustment

Weight : 1250 ± 10g

Dimensions : 450 x 222 x 40 mm

Compatible : Windows / Mac / Linux

3. Combination Keys

FN + F1	Multimedia Player
FN + F2	Volume Down
FN + F3	Volume Up
FN + F4	Mute
FN + F5	Stop
FN + F6	Prev Track
FN + F7	Play / Pause
FN + F8	Next Track
FN + F9	Email
FN + F10	Homepage
FN + F11	My Computer
FN + F12	Calculator
FN + ~	Lighting Customization
FN + →	Change Backlight Color
FN + ←	Change Backlight Direction
FN + ↑	Increase Backlight Brightness
FN + ↓	Decrease Backlight Brightness
FN + - _	Increase Backlight Speed
FN + = +	Decrease Backlight Speed
FN + Win-L	Windows Lock
FN + Esc	Reset Settings (Press FN + Esc, then press F1 F3 F5 in sequence)

* There are 5 levels of Backlight Brightness (0% - 20% - 40% - 60% - 80% - 100%)

* There are 5 levels of Backlight Speed

4. LED Light Effect Button

FN + Insert (A1) : Trial, Breathing, Constant Light

FN + Home (A2) : Ripples, Treading Snow Without Trace, Escape

FN + PgUp (A3) : Roc Spreads Its Wings, Accumulates and Grows, Rains


FN + Delete (A4) : Drifting Effects (Tide, Colorful Clouds Flying, Winding Peaks)

FN + End (A5) : Hundreds of Flower Bloomings, Undercurrent Surging, Meteor Chasing the Moon


FN + PgDn (A6) : Unity, Speed and Passion, Both Ways

5. Lighting Customization Tutorial


1. Press the **FN + ~** keys to enter the lighting customization and the indicator light will start flashing.



2. Press the **FN + Right Arrow** key to set the color, and the ~ key will start to light up. Each time you press the FN + Right Arrow key, the ~ key will change to a different color.



Select the desired color and press one to set the color.
(If the ~ button is red, press the A button to make it red)



3. Once customized, press **FN + ~** to save the settings.

RYUNIX



FO-104

REMOVABLE MECHANICAL GAMING KEYBOARD

BUKU MANUAL



BUKU MANUAL KEYBOARD FO-104 [ID]



1. Fitur

- **Layout Keyboard Fullsize**
Keyboard mechanical dengan 104 tombol
- **Removable Switch (3-Pin)**
Dilengkapi dengan outemu switch yang dapat diganti dengan switch lainnya
- **Efek Lampu LED**
Mudah mengganti efek lampu LED dengan 6 tombol
- **Tombol Pintas**
12 tombol pintas untuk fungsi multimedia
- **Tombol Full Anti-Ghosting**
Seluruh tombol anti-ghosting untuk pengetikan yang baik
- **Koneksi Kabel USB**
Koneksi keyboard dengan kabel PVC USB 1.8m

2. Spesifikasi

Jumlah Tombol	: 104 Tombol + 12 Tombol Pintas
Anti-Ghosting	: Full Anti-Ghosting
Tipe Keyboard	: Keyboard Mekanikal
Switch	: Switch Outemu Removable
Koneksi	: USB
Panjang Kabel	: 1.8m
Tipe Kabel	: Kabel PVC
Backlight	: Lampu Backlight RGB 6 Level Pengaturan Kecerahan
Berat	: 1250 ± 10g
Dimensi	: 450 x 222 x 40 mm
Kompatibel	: Windows / Mac / Linux

3. Tombol Kombinasi

FN + F1	Multimedia Player
FN + F2	Volume Down
FN + F3	Volume Up
FN + F4	Mute
FN + F5	Stop
FN + F6	Prev Track
FN + F7	Play / Pause
FN + F8	Next Track
FN + F9	Email
FN + F10	Homepage
FN + F11	My Computer
FN + F12	Calculator
FN + ~	Kustomisasi Lighting
FN + →	Mengubah Warna Backlight
FN + ←	Mengubah Arah Backlight
FN + ↑	Meningkatkan Kecerahan Backlight
FN + ↓	Menurunkan Kecerahan Backlight
FN + - _	Meningkatkan Kecepatan Backlight
FN + = +	Menurunkan Kecepatan Backlight
FN + Win-L	Windows Lock
FN + Esc	Reset Pengaturan (Tekan FN + Esc, lalu tekan F1 F3 F5 secara berurutan)

* Tingkat Kecerahan Backlight terdapat 5 level (0% - 20% - 40% - 60% - 80% - 100%)


* Tingkat Kecepatan Backlight terdapat 5 level

4. Tombol Efek Lampu LED


- FN + Insert (A1)** : Trial, Breathing, Constant Light
- FN + Home (A2)** : Ripples, Treading Snow Without Trace, Escape
- FN + PgUp (A3)** : Roc Spreads Its Wings, Accumulates and Grows, Rains
- FN + Delete (A4)** : Drifting Effects (Tide, Colorful Clouds Flying, Winding Peaks)
- FN + End (A5)** : Hundreds of Flower Bloomings, Undercurrent Surging, Meteor Chasing the Moon
- FN + PgDn (A6)** : Unity, Speed and Passion, Both Ways

5. Tutorial Kustomisasi Lighting


1. Tekan tombol **FN + ~** untuk memasuki kustomisasi lighting dan lampu indikator mulai berkedip.



2. Tekan Tombol **FN + Panah Kanan** untuk mengatur warna dan tombol ~ mulai menyala. Setiap kali menekan tombol FN + panah kanan, tombol ~ berubah menjadi warna yang berbeda.



Pilih warna yang diinginkan dan tekan salah satu untuk mengatur warna. (Jika tombol ~ berwarna merah, tekan tombol A untuk menjadi merah)



3. Setelah di kustom, tekan **FN + ~** untuk menyimpan pengaturan.